

## Cartuchos e Impressoras Brother

Modelo da Impressora	Cartucho Toner
HL-1110 / 1112 / DCP-1512 / MFC-1810 / 1815	TN-1060
HL-2140 / HL-2170W / DCP-7040 / MFC-7440N / MFC-7840W	TN-330
HL-5452DN / DCP-8112DN / DCP-8152DN / MFC-8512DN	TN-3332
HL-5452DN / DCP-8112DN / DCP-8152DN / MFC-8512DN	TN-3382
HL-2010 / DCP-7020 / MFC-7220 / 7420 / 7820N / HL-2040	TN-350
HL-2140 / HL2170W / DCP-7040 / MFC-7440N / MFC7840W	TN-360
HL2130 / DCP7055	TN-410
HL-2240 / HL-2270DW / DCP-7065DN / MFC-360N / MFC7460DN	TN-420
HL-2240 / HL-2270DW / DCP-7065DN / MFC7360N / MFC7460DN	TN-450
MFC-9600	TN-460
HL-5240 / DCP-8060 / HL-5250DNT / MFC-8860DN / DCP-8065DN	TN-580
DCP-8070D / DCP-8080DN / HL-5340D / MFC-8480DN	TN-650