

## Cartuchos e Impressoras HP Color LaserJet

| Série da impressora                         | Modelos de impressora                                                                                                                    | Cartuchos da impressora                |
|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------|
| HP LaserJet Enterprise 500 Color série M551 | HP LaserJet Enterprise 500 color M551n<br>HP LaserJet Enterprise 500 color M551dn<br>HP LaserJet Enterprise 500 color M551xh             | CE400X, CE400A, CE401A, CE402A, CE403A |
| HP Color LaserJet 1600                      | HP Color LaserJet 1600                                                                                                                   | Q6000A, Q6001A, Q6002A, Q6003A         |
| HP Color LaserJet série 2600                | HP Color LaserJet 2605<br>HP Color LaserJet 2605dn<br>HP Color LaserJet 2605dtn                                                          | Q6000A, Q6001A, Q6002A, Q6003A         |
| HP Color LaserJet série 3000                | HP Color LaserJet 3000<br>HP Color LaserJet 3000n<br>HP Color LaserJet 3000dn<br>HP Color LaserJet 3000dtn                               | Q7560A, Q7561A, Q7562A, Q7563A         |
| HP Color LaserJet série 3500                | HP Color LaserJet 3500<br>HP Color LaserJet 3500N                                                                                        | Q2670A, Q2671A, Q2672A, Q2673A         |
| HP Color LaserJet série 3550                | HP Color LaserJet 3550<br>HP Color LaserJet 3550N                                                                                        | Q2670A, Q2671A, Q2672A, Q2673A         |
| HP Color LaserJet série 3700                | HP Color LaserJet 3700<br>HP Color LaserJet 3700N<br>HP Color LaserJet 3700DN<br>HP Color LaserJet 3700DTN<br>HP Color LaserJet 3700DTNS | Q2670A, Q2681A, Q2682A, Q2683A         |
| HP Color LaserJet série 3800                | HP Color LaserJet 3800<br>HP Color LaserJet 3800N<br>HP Color LaserJet 3800DN<br>HP Color LaserJet 3800DTN                               | Q6470A, Q7581A, Q7582A, Q7583A         |
| HP Color LaserJet série 4600                | HP Color LaserJet 4600<br>HP Color LaserJet 4600N<br>HP Color LaserJet 4600DN<br>HP Color LaserJet 4600DTN<br>HP Color LaserJet 4600HDN  | C9720A, C9721A, C9722A, C9723A         |
| HP Color LaserJet 4610n                     | HP Color LaserJet 4610n                                                                                                                  | C9720A, C9721A, C9722A, C9723A         |
| HP Color LaserJet série 4650                | HP Color LaserJet 4650<br>HP Color LaserJet 4650N<br>HP Color LaserJet 4650DN<br>HP Color LaserJet 4650DTN<br>HP Color LaserJet 4650HDN  | C9720A, C9721A, C9722A, C9723A         |
| HP Color LaserJet série 4700                | HP Color LaserJet 4700<br>HP Color LaserJet 4700n<br>HP Color LaserJet 4700dn<br>HP Color LaserJet 4700dtn<br>HP Color LaserJet 4700ph+  | Q5950A, Q5951A, Q5952A, Q5953A         |

|                                    |                                                                                                                                                                                                            |                                |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| HP Color LaserJet série 4730       | HP Color LaserJet 4730<br>HP Color LaserJet 4730 MFP<br>HP Color LaserJet 4730x MFP<br>HP Color LaserJet 4730xs MFP<br>HP Color LaserJet 4730xm MFP                                                        | Q5950A, Q5951A, Q5952A, Q5953A |
| HP Color LaserJet série 5500       | HP Color LaserJet 5500<br>HP Color LaserJet 5500n<br>HP Color LaserJet 5500dn<br>HP Color LaserJet 5500dtn<br>HP Color LaserJet 5500hdn                                                                    | C9730A, C9731A, C9732A, C9733A |
| HP Color LaserJet série 5550       | HP Color LaserJet 5550n<br>HP Color LaserJet 5550dn<br>HP Color LaserJet 5550dtn<br>HP Color LaserJet 5550hdn<br>HP Color LaserJet 5550dsn                                                                 | C9730A, C9731A, C9732A, C9733A |
| HP Color LaserJet série 9500       | HP Color LaserJet 9500<br>HP Color LaserJet 9500N<br>HP Color LaserJet 9500DN<br>HP Color LaserJet 9500HDN<br>HP Color LaserJet 9500GN<br>HP Color LaserJet 9500GP                                         | C8550A, C8551A, C8552A, C8553A |
| HP Color LaserJet Pro série CP1020 | HP LaserJet CP1021<br>HP LaserJet CP1022<br>HP LaserJet CP1023<br>HP LaserJet CP1025<br>HP LaserJet CP1025nw<br>HP LaserJet CP1026nw<br>HP LaserJet CP1027nw<br>HP LaserJet CP1028nw                       | CE310A, CE311A, CE312A, CE313A |
| HP Color LaserJet série CP1210     | HP Color LaserJet CP1213<br>HP Color LaserJet CP1214<br>HP Color LaserJet CP1215<br>HP Color LaserJet CP1216<br>HP Color LaserJet CP1217                                                                   | CB540A, CB541A, CB542A, CB543A |
| HP Color LaserJet série CP1510     | HP Color LaserJet CP1513n<br>HP Color LaserJet CP1514n<br>HP Color LaserJet CP1515n<br>HP Color LaserJet CP1516n<br>HP Color LaserJet CP1517ni<br>HP Color LaserJet CP1518ni<br>HP Color LaserJet CP1519ni | CB540A, CB541A, CB542A, CB543A |
| HP Color LaserJet Pro série CP1520 | HP LaserJet CP1521n<br>HP LaserJet CP1522n<br>HP LaserJet CP1523n<br>HP LaserJet CP1525n<br>HP LaserJet CP1525nw<br>HP LaserJet CP1526nw<br>HP LaserJet CP1527nw<br>HP LaserJet CP1528nw                   | CE320A, CE321A, CE322A, CE323A |
| HP Color LaserJet série CP1600     | HP Color LaserJet CP1600                                                                                                                                                                                   | Q6000A, Q6001A, Q6002A, Q6003A |

|                                           |                                                                                                                                                                                                                                                                                                                                                          |                                        |
|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------|
| HP Color LaserJet série CP2020            | HP Color LaserJet CP2024<br>HP Color LaserJet CP2024n<br>HP Color LaserJet CP2024dn<br>HP Color LaserJet CP2025<br>HP Color LaserJet CP2025n<br>HP Color LaserJet CP2025dn<br>HP Color LaserJet CP2026<br>HP Color LaserJet CP2026n<br>HP Color LaserJet CP2026dn<br>HP Color LaserJet CP2027<br>HP Color LaserJet CP2027n<br>HP Color LaserJet CP2027dn | CC530A, CC531A, CC532A, CC533A         |
| HP Color LaserJet série CP2600            | HP Color LaserJet CP2600                                                                                                                                                                                                                                                                                                                                 | Q6000A, Q6001A, Q6002A, Q6003A         |
| HP Color LaserJet série CP3505            | HP Color LaserJet CP3505<br>HP Color LaserJet CP3505n<br>HP Color LaserJet CP3505dn<br>HP Color LaserJet CP3505x<br>HP Color LaserJet CP3505xh                                                                                                                                                                                                           | Q6470A, Q7581, Q7582A, Q7832A          |
| HP Color LaserJet série CP3520            | HP Color LaserJet CP3525<br>HP Color LaserJet CP3525n<br>HP Color LaserJet CP3525dn<br>HP Color LaserJet CP3525x                                                                                                                                                                                                                                         | CE250X, CE250A, CE251A, CE252A, CE253A |
| HP Color LaserJet série CP4005            | HP Color LaserJet CP4005<br>HP Color LaserJet CP4005n<br>HP Color LaserJet CP4005dn                                                                                                                                                                                                                                                                      | CB400A, CB401A, CB402A, CB403A         |
| HP Color LaserJet série CP4025            | HP Color LaserJet CP4025n<br>HP Color LaserJet CP4025dn<br>HP Color LaserJet CP4020                                                                                                                                                                                                                                                                      | CE260A, CE261A, CE262A, CE263A         |
| HP Color LaserJet série CP4520            | HP Color LaserJet CP4520<br>HP Color LaserJet CP4525n<br>HP Color LaserJet CP4525dn<br>HP Color LaserJet CP4525xh                                                                                                                                                                                                                                        | CE260X, CE260A, CE261A, CE262A, CE263A |
| HP Color LaserJet Pro série CP5225        | HP Color LaserJet CP5225<br>HP Color LaserJet CP5225n<br>HP Color LaserJet CP5225dn<br>HP Color LaserJet CP5225xh                                                                                                                                                                                                                                        | CE740A, CE741A, CE742A, CE743A         |
| HP Color LaserJet Enterprise série CP5520 | CP5520 HP Color LaserJet Enterprise<br>CP5525xh HP Color LaserJet Enterprise<br>CP5525n HP Color LaserJet Enterprise<br>CP5525dn HP Color LaserJet Enterprise                                                                                                                                                                                            | CE270A, CE271A, CE272A, CE273A         |
| HP Color LaserJet série CP6015            | HP Color LaserJet CP6015n<br>HP Color LaserJet CP6015dn<br>HP Color LaserJet CP6015de<br>HP Color LaserJet CP6015dne<br>HP Color LaserJet CP6015x<br>HP Color LaserJet CP6015xh                                                                                                                                                                          | CB380A, CB381A, CB382A, CB383A         |

Fonte:

<http://h10025.www1.hp.com/ewfrf/wc/document?cc=br&lc=pt&dlc=pt&docname=c02740308#N946>